

## STENCIL AND MARKING FLUID

### NOTE

Our glass marking fluid is non-toxic and non-corrosive. Protective clothing is not required during application.



Clean area of glass to be marked with a clean dry cloth. DO NOT wet the glass prior to application of stencils.




Peel off the stencil and retain the backing paper for later use.



Place the adhesive side of the stencil on the glass.




To avoid finger contact with the glass, use the piece of backing material to press the stencil firmly against the surface to ensure a tight bond.



Apply fluid to the stencil with the brush provided, making sure that all the letters and numbers are filled. Leave fluid in place for between 25 and 90 seconds.



Use Water to neutralise the fluid before removing the stencil



Peel off the stencil and discard

